

Use to measure active or passive joint range of motion (ROM) in 1° increments. Can be used laterally, volarly, or dorsally along the long axes of the joint. Ideal for joints of the hand and wrist.