


Easy Turn Lampswitch

Lampswitch turns smoothly with just a light touch.

Replace small lamp knobs with the large, three-spoked Easy Turn Lampswitch.

Ideal for anyone with a limited grasp, such as people with arthritis.

Installs in seconds.



Easy Turn Lampswitch

The increased size and shape of the Easy Turn Lampswitch make it simple to grasp and turn for anyone with a limited grasp. Installation takes just seconds.

1. Unscrew your lamp's original knob by turning counterclockwise.
2. Remove the Easy Turn Lampswitch from the packaging and screw onto the lamp by turning clockwise.



**Easy Turn Lampswitch
NC28750**



North Coast