

# S-TRc TREADMILL



- Pre-wired for S-Series PVS entertainment system.
- User-friendly console and keypad feature a large service scrolling message window, user-specific workout programs, a dedicated heart rate display, Polar® telemetry and multiple cup and accessory holder.
- Two personal fans offers adjustable speed settings and are integrated into the console.
- Optimal extended rubber-coated handrails create a more secure experience.
- SoftTrac® triple cell cushioning system provides maximum shock absorption.

## S-TRc TREADMILL

Model S-TRc

user weight capacity	running surface	width	length	height
500 lbs (227 kg)	60" x 20" (152 x 51 cm)	32" (81.3 cm)	81" (206 cm)	58" (147.3 cm)

## FEATURES AND SPECIFICATIONS

**OVERALL WEIGHT:** 450 lbs (204 kg)

**STEP-UP HEIGHT:** 7" (17.8 cm)

**FRAME:** Custom powder-coated steel uniframe

**MOTOR DRIVE:** 5 HP AC

**ELECTRICAL:** 110 volt, dedicated NEMA 5-20 cord; 220 volt, dedicated NEMA 6-15 cord (optional)\*

**CERTIFICATION:** UL/CSA, CE, FCC, or CISPR

**SUSPENSION:** Soft Trac® triple cell neoprene rubber, Deck System: Reversible 1" (2.5 cm) composite fiberboard, waxing not required

**ROLLERS:** 3" (7.6 cm) sealed bearings

**COLORS:** Frame: Star Trac Silver, Shrouds: Slate Gray, Accents: Black

**INCLINE RANGE:** 0 to 15% in 0.5% increments

**SPEED RANGE:** 0.5 to 12.5mph\*\* (0.8 to 20 km/h\*\*) in 0.1 mph (0.1 km/h) increments

**HR MONITORING:** Polar® Telemetry and Contact Heart Rate System

**DISPLAY:** Intuitive, tactile response keypad with LED technology

**READOUTS:** Large 8-character message window; Dedicated: Time, distance, incline, speed, heart rate, 1/4-mile motivational track, profile; Scrolling: calories, METs, course profile

**PROGRAMS:** 13 programs including Dynamic Heart Rate Control®, Constant Heart Rate Control, Quick Start, Burn Calories, Manual, Increase Endurance, Fitness Test (Modified Balke Ware)

**STANDARD FEATURES:** Personal cooling fans, rubber-coated handrails, wrap-around Aero Bar, dedicated heart rate display, Entertainment Solutions Ready, Safety Lanyard

**ENTERTAINMENT:** Pre-wired for S Series Personal Viewing Screen kit

**WARRANTY:** Commercial warranty: 2-year parts warranty, 1-year labor warranty, 5-year parts and labor warranty on the motor and motor control board; Light commercial setting: 3-year warranty on parts and labor, 5-year parts and labor warranty on the motor and motor control board (USA and Canada only)\*\* (Light Commercial warranty for all non dues paying facilities 3 years parts/labor)



©2008 Star Trac. All rights reserved. Star Trac, the Star Trac logo, Soft Trac and Dynamic Heart Rate Control are registered trademarks of Unisen, Inc. Polar is a registered trademark of Polar Electro, Inc. \*Dedicated 110 volt/20 amp circuit. Mandatory dedicated hot and dedicated neutral wires. Ground wire may be shared by up to four treadmills. Line cord plug: 5-20 NEMA. \*\*Default product settings is 0.5 to 12.5 mph (0.8 to 20 km/h) in 0.1 mph (0.1 km/h) increments. Light commercial warranty: (Non-dues paying facility with < 8 of use per day only, not warranted for use in dues-paying facilities or facilities with > or equal to 8 hours of use per day) Parts are covered for a period of three (3) years from date of purchase and labor is covered for a period of three (3) years from the date of purchase. Wear items, such as drive belts and upholstery are warranted for a period of one (1) year from the date of purchase. Frame welds are warranted for the life of product. Additional warranties may be available based of facility type and daily usage. (USA and Canada only)